USER'S MANUAL
Part 2

2.4 GHz Cordless Telephone with Caller ID/Call Waiting 1440/1140



For Customer Service Or Product Information, Visit Our Website At www.telephones.att.com

Please also read **Part 1 — Important Product Information**

© 2002 Advanced AmericanTelephones. All Rights Reserved.
AT&T and the Globe Design are trademarks of AT&T Corp., licensed to Advanced AmericanTelephones.

Visit us at www.telephones.att.com

© 2002 Advanced American Telephones.
All Rights Reserved.
AT&T and the Globe Design are
trademarks of AT&TCorp., licensed to
Advanced American Telephones.

Printed in China. Issue 2AT&T 02/03

CONTENTS

CONTENTS

BEFORE YOU BEGIN 1
Parts List 1
Choose a Location for Your Phone 2
About Caller Identification 2

INSTALLATION 3
Before You Install 3
Table/Desk Installation 4
Wall Installation 6

TELEPHONE OPERATION 7
Make a Call 7
Answer a Call 7
End a Call 7
Change Channel 7
Redial 7
Handset Volume 7
Flash/Call Waiting 7
Hold 7
Page/Handset Locator 8
Handset Ringer Style/ Battery Save 9
Temporary Tone Dialing 9
Headset Jack 10
Operating Range 10

TELEPHONE MEMORY 11
Store a Number/Name in Memory 11
Edit a Number/Name Stored in Memory 14
Delete a Number/Name Stored in Memory 15
Dial a Memory Number 16

TELEPHONE DIRECTORY 17
Store a Number/Name in the Directory 17
Edit a Number/Name Stored in the Directory 19
Delete a Number/Name Stored in the Directory 20
Dial a Number from the Directory 21

CALLER ID OPERATION 22
About Call History 22
Review Call History 23
Turn Off Base NEW CALL Indicator 23
Delete Records from Call History 24
Dial a Displayed Number 25
Store a Call History Record in the Directory 26
Display Screen Messages 27

BATTERIES 28
Charge the Handset Battery Pack 28
Replace the Handset Battery Pack 29

IN CASE OF DIFFICULTY 30

DEFAULT SETTINGS 34

TECHNICAL SPECIFICATIONS . . 35

INDEX 36

BEFORE YOU BEGIN

Parts List

Your box should include:



Choose a Location for Your Phone

For best reception quality, choose a location for the base unit of your new telephone:

- Away from microwave ovens
- Away from TVs,VCRs,stereo equipment and computers (Cordless telephones operate at a radio frequency that may cause interference with these types of equipment.)
- Away from extreme heat or cold (For example: radiators,direct sunlight,air ducts,air conditioning and open windows)
- Away from other cordless telephones (Note:2.4 GHz Digital Spread Spectrum Telephones may cause interference with this telephone.)
- Away from metal walls or cabinets,and
- Near an electrical outlet not controlled by a wall switch.

About Caller Identification (Caller ID)

This product has a Caller ID with Call Waiting feature that works with service from your local phone service provider.

Caller ID with Call Waiting lets you see who's calling before you answer the phone, even when you're on another call.

You may need to change your phone service to use this feature. Contact your phone service provider if:

- You have both Caller ID and Call Waiting,but as separate services (you may need combined service)
- You have only Caller ID service,or only Call Waiting service
- You don't subscribe to any Caller ID or Call Waiting services.

You can use this product with regular Caller ID service,and you can use this product's other features without subscribing to either Caller ID or combined Caller ID with Call Waiting service.

There are fees for Caller ID services,and they may not be available in all areas.

This product can provide information only if both you and the caller are in areas offering Caller ID service,and if both telephone companies use compatible equipment.

INSTALLATION

Before You Install

1 Choose a location for the base near an electrical outlet and a telephone jack.

This phone requires a modular telephone jack and a standard electrical outlet (110v AC) not controlled by a wall switch.

2 Install the handset battery.

Use only the following AT&T Batteries 3301,SKU#91076.


a) Remove battery compartment cover by pressing on the indentation and sliding downward.
b) Align two holes in plug with socket pins,and snap the plug into place.
c) Place battery pack in compartment with the wires in the lower left corner, along the bottom of the battery pack.
d) Replace cover by sliding it up into place.

3 Attach belt clip to the cordless handset *(optional)*.



NOTE: ***Install the base unit away from electronic equipment such as personal computers, television sets or microwave ovens. Avoid excessive heat, cold, dust or moisture.***

Table/Desk Installation



1 Connect the telephone line cord.

2 Connect the power cord.

3 Charge the handset battery.

Place the handset in the base. Charge the battery for at least 12 hours the first time.

4 Check for dial tone.

After the batteries are charged,pick up the handset and press PHONE; you should hear a dial tone.

5 Set the dial mode.

If you have touch tone service,the phone is ready to use as soon as the batteries are charged.

If you have dial pulse (rotary) service, you'll need to change the dial mode.

- Press PROG/CHAN on the handset to enter programming mode.
- Press ◀ or ▶ until the screen displays DIAL MODE: and the currently selected mode.
- Press SEL. The current setting blinks.
- Press ◀ or ▶ to select TONE or PULSE.
- Press SEL, to save the displayed mode.

6 Set Time and Date.

- Press PROG/CHAN,then press ◀ or ▶ until the screen displays:DATE/TIME. Press SEL.
- The month is flashing. Press ◀ or ▶ until the screen displays the correct month. Press SEL.
- The day is flashing. Press ◀ or ▶ until the screen displays the correct day. Press SEL.
- The hour is flashing. Press ◀ or ▶ until the screen displays the correct hour. Press SEL.
- The minute is flashing. Press ◀ or ▶ until the screen displays the correct minute. Press SEL.
- AM or PM is flashing. Press ◀ or ▶ to choose between AM and PM. Press SEL.

NOTE: ***You can choose to set the time manually, or you can allow it to be automatically set with incoming Caller ID Information.***

Wall Installation

1 Connect the telephone line cord.

2 Connect the power cord.

3 Mount the base on the wall.



a) Align holes on base with mounting studs on wall jack.

b) Pull base down on mounting studs until it locks into place.

4 Follow Steps 3–6 in Table/Desk Installation.

TELEPHONE OPERATION



Make a Call

Press [PHONE], then dial the number

— OR —

Dial the number (use ◄ to backspace and correct digits),then press [PHONE] to call.

Answer a Call

Press any key except [OFF].

End a Call

Press [OFF]

— OR —

Place handset in base.

Change Channel

Press [PROG/CHAN] to switch to a clearer channel while on a call.

Redial

Press [PHONE], then press [REDIAL/PAUSE] to call last number dialed (up to 32 digits).

— OR —

Press [REDIAL/PAUSE], then press [PHONE] to call last number dialed.While handset idle,press [REDIAL/PAUSE] twice to delete the record.

Handset Volume

While on a call,press ◄ or ► to adjust volume of what you hear.A double beep will be sounded when reach minimum or maximum volume.

Flash/Call Waiting

1. When you receive a Call Waiting signal,press [PHONE]/[FLASH] to connect to the new call.
2. Press [PHONE]/[FLASH] again to return to the original call.

Hold

Press [HOLD] to put a call on hold. Press [HOLD] again or [PHONE] to release hold

— OR —

Pick up an extension phone will release hold and return the handset to the idle (on hook) mode.

Page/Handset Locator

Press to page the handset for up to 60 seconds. Press again to cancel,or press OFF on handset.



If you subscribe to telephone company voice mail with a visual message waiting signal, light flashes when you have voice mail waiting.

Flashes when you have unreviewed call information.

Flashing: handset is in use or there is an incoming call.

On steadily: handset is charging in base.

Handset Ringer Style/Battery Save

You can select from four different handset ringer styles,or turn the ringer off and extend the battery life.

1. Make sure the handset is off.
2. Press PROG/CHAN to enter programming mode.
3. Press ◀ or ▶ until the screen displays RINGER: and the current setting.
4. Press SET. The current setting is flashing.
5. Press ◀ or ▶ to select 1, 2, 3, 4, or OFF. You will hear a sample of each ring.
6. Press SET to choose the displayed ringer setting.

Temporary Tone Dialing

If you have dial pulse (rotary) service, you can change from dial pulse to touch tone dialing during a call by pressing TONE. This is useful if you need to send touch tone signals for access to telephone banking or long-distance services.

1. Dial the number.
2. Press TONE. Buttons pressed after this send touch tone signals.
3. After you hang up,the phone automatically returns to dial pulse (rotary) service.

Headset Jack

You can use this telephone hands-free when you install any AT&T 2.5 mm headset, purchased separately.

Plug the headset into the jack located on the right side of the handset (under the small rubber flap). Do not force the connection, but make sure the plug fits securely.

Operating Range

This cordless telephone operates within the maximum power allowed by the Federal Communications Commission (FCC). Even so,this handset and base can communicate over only a certain distance — which can vary with the locations of the base and handset,the weather, and the construction of your home or office. For best performance, keep the base antenna fully upright.

If you receive a call while you are out of range, the handset might not ring — or if it does ring,the call might not connect when you press PHONE. Move closer to the base,then press PHONE to answer the call.

If you move out of range during a phone conversation, you might hear noise or interference. To improve reception,move closer to the base.

If you move out of range without pressing OFF, your phone will be left "off the hook." To hang up properly, walk back into range, periodically pressing OFF.

TELEPHONE MEMORY

This cordless phone can store 10 telephone numbers with names,each up to 16 digits long in memory locations you assign (0-9).

NOTE: ***Press*** OFF ***at any time to exit memory dial mode.***



This cordless phone can store an additional 40 telephone numbers with names alphabetically in the directory. See TELEPHONE DIRECTORY for instructions.

Store a Number/Name in Memory

1 Press PROG/CHAN. Then press ◄ or ► until the screen displays

```
MEM DIAL
```

2 Press SEL or MEMORY. The screen displays

```
ENTER 0-9
```

3 Press the key (0-9) for the memory location where you're storing this entry. If the selected location is empty, the screen displays

```
ENTER NAME
```

NOTE: ***If the location is not empty, the current entry is displayed along with the choices*** DIAL EDIT ERASE ***after pressing*** SEL ***key. Press*** OFF ***to exit memory dial mode and start again, or follow the instructions to dial, edit or erase the current entry.***

4 Using the chart below, enter up to 15 characters for the name you're storing with the number. Use ◄ to backspace and make corrections;use ► to advance and add a space.

Dial Key	Presses 1	2	3	4	5	6
1	1					
2	A	B	C	2		
3	D	E	F	3		
4	G	H	I	4		
5	J	K	L	5		
6	M	N	O	6		
7	P	Q	R	S	7	
8	T	U	V	8		
9	W	X	Y	Z	9	
0	0					
*	*					
#	&	’	,	-	.	#



5 When you finish entering the name,press SEL or PROG/CHAN. The screen displays

```
ENTER NUMBER
```

6 Enter the telephone number. Use ◀ to backspace and make a correction. Press REDIAL/PAUSE to store a pause in the dialing sequence.

—OR—

Press REDIAL/PAUSE to display the last number (up to 16 digits) dialed from this phone.

7 Press SEL or PROG/CHAN to store your entry. The screen displays

```
DISTINCT RING? N
9735550123
```



8 Press ◀ or ▶ to change the setting. Choose Y (for Yes) if you wish the phone to alert you to calls from this number by changing to a distinctive ringing pattern after the first ring. Choose N (for No) for a normal ringing pattern.

9 Press SEL or PROG/CHAN to confirm your selection. If you chose Y in **Step 8**, a D will be displayed with the memory entry.

10 To add additional memory locations follow procedures 1-9 again.



Edit a Number/Name Stored in Memory

1 Press MEMORY. The screen displays

```
ENTER 0-9
```

2 Press the memory location key of the entry you wish to edit.

3 When the screen displays the number you want to edit,press SEL. Then press ◀ or ▶ until EDIT flashes.

```
DIAL EDIT ERASE
9735550123
```

4 Press SEL. The screen displays the name and number. The flashing cursor appears at the end of the name. Use ◀, ▶ and the dial pad keys to edit the name. Press SEL to move on to edit the number. Use ◀ to backspace and make a correction.Press SEL to move on to edit the Distinctive Ring setting.

5 Press SEL to save the edited information.

Delete a Number/Name Stored in Memory



1 Press [MEMORY]. The screen displays

```
ENTER 0-9
```

2 Press the memory location key of the entry you wish to delete.

3 When the screen displays the number you want to delete,press [SET]. Then press ◀ or ▶ until ERASE flashes.

```
DIAL EDIT ERASE
9735550123
```

4 Press [SET]. The screen displays ERASE NO YES and the number. The current choice flashes.

5 Press ◀ or ▶ until YES flashes.

6 Press [SET].

Dial a Memory Number

1 Press MEMORY. The screen displays



2 Enter the memory location key of the entry you want to dial.

3 Press PHONE to dial the displayed memory number.

TELEPHONE DIRECTORY

This cordless phone can store 40 telephone numbers with names,each up to 16 digits long. Entries are stored alphabetically.

NOTE: ***Press*** OFF ***at any time to exit directory.***

Store a Number/Name in the Directory



1 Press PROG/CHAN. The screen displays

```
DIREC
```

2 Press SET. The screen displays

```
ENTER NAME
```

3 Using the chart below, enter up to 15 characters for the name you're storing with the number. Use ◀ to backspace and make corrections;use ▶ to advance and add a space.

	Presses					
Dial Key	1	2	3	4	5	6
1	1					
2	A	B	C	2		
3	D	E	F	3		
4	G	H	I	4		
5	J	K	L	5		
6	M	N	O	6		
7	P	Q	R	S	7	
8	T	U	V	8		
9	W	X	Y	Z	9	
0	0					
*	*					
#	&	'	,	-	.	#



4 When you finish entering the name,press SEL or PROG/CHAN. The screen displays

```
ENTER NUMBER
```

5 Enter the telephone number. Use ◀ to backspace and make a correction. Press REDIAL/PAUSE to store a pause in the dialing sequence.

—OR—

Press REDIAL/PAUSE to display the last number (up to 16 digits) dialed from this phone.

6 Press SEL or PROG/CHAN. The screen displays

```
DISTINCT RING? N
9735550123
```

7 Press ◀ or ▶ to change the setting. Choose Y (for Yes) if you wish the phone to alert you to calls from this number by changing to a distinctive ringing pattern after the first ring. Choose N (for No) for a normal ringing pattern.

8 Press SEL or PROG/CHAN to confirm your selection. If you chose Y in **Step 7**, a D will be displayed with the directory entry.

NOTE: ***When memory is full the screen displays*** MEMORY FULL***, an error tone sounds, and you will not be able to store a new number until you delete a stored number.***

Edit a Number/Name Stored in the Directory



1 Press ▶ (DIR). The screen displays

```
DIREC
```

2 Press ◀ or ▶ to scroll alphabetically through entries stored in memory

—OR—

Press the dial pad key for the first letter of the entry you want to edit.

3 When the screen displays the number you want to edit,press SEL. Then press ◀ or ▶ until EDIT flashes.

```
DIAL EDIT ERASE
9735550123
```

4 Press SEL. The screen displays the name and number. The flashing cursor appears at the end of the name. Use ◀, ▶ and the dial pad keys to edit the name. Press SEL to move on to edit the number. Use ◀ to backspace and make a correction.Press SEL to move to edit the Distinctive Ring setting.

5 Press SEL to save the edited information.



Delete a Number/Name Stored in the Directory

1 Press ▶ (DIR). The screen displays

```
D I R E C
```

2 Press ◀ or ▶ to scroll alphabetically through entries stored in memory

—OR—

Press the dial pad key for the first letter of the entry you want to delete.

3 When the screen displays the number you want to delete,press SET. Then press ◀ or ▶ until ERASE flashes.

```
DIAL EDIT ERASE
9735550123
```

4 Press SET. The screen displays ERASE NO YES and the number. The current choice flashes.

5 Press ◀ or ▶ until YES flashes.

6 Press SET. You'll hear a long beep confirming the deletion.

Dial a Number from the Directory



1 Press ▶ (DIR). The screen displays

```
D I R E C
```

2 Press ◀ or ▶ to scroll alphabetically through entries stored in memory

—OR—

Press the dial pad key for the first letter of the entry you want to dial.

3 When the screen displays the number you want to dial,press SET. Then press ◀ or ▶ until DIAL flashes.

```
DIAL EDIT ERASE
9735550123
```

4 Press SET. The phone automatically dials the number.

—OR—

When the screen displays the number you want to dial,press PHONE.

NOTE: ***To dial a memory number refer to page 16.***

CALLER ID OPERATION

About Call History

If you subscribe to Caller ID service with your local phone service provider, this phone stores all incoming calls (up to 99 at the handset) with valid Caller ID information in the call log. Name, number, time and date information can all be stored,if they are sent with the call. Calls are automatically stored in the order they are received,with call "1" stored as the oldest call. The call history number appears in the bottom right corner of the screen along with **NEW** for unreviewed or **OLD** for previously reviewed call information.



NOTE: ***Press*** OFF ***at any time to exit call history.***



Review Call History

The screen displays call information for about 15 seconds after it has been received.

1 Press ◀ (CID) to view call history. The screen displays

2 Use ◀ and ▶ to scroll through records in call history.

Turn Off Base NEW CALL Indicator

After reviewing all new calls,press OFF on the handset.

NOTE: ***If the light does not go off, you may still have unreviewed (new) calls somewhere in your call history. Make sure you review your entire call history.***



Delete Records from Call History

Delete a Specific Call

1 Locate the record you want to delete from call history.

2 Press SET, then press ◄ or ► until ERASE flashes.

3 Press SET. The screen displays



The current choice flashes.

4 Press ◄ or ► until YES flashes.

5 Press SET. You'll hear a long beep confirming the deletion.

Delete All Calls

1 While viewing call history, press SET, then press ◄ or ► until ERASE flashes.

2 Press SET. The screen displays



The current choice flashes.

3 Press ◄ or ► until ALL flashes,then press SET. The screen displays ERASE ALL NO YES. The current choice flashes.

4 Press ◄ or ► until YES flashes.

5 Press SET. You will hear a long beep confirming the deletion.

Dial a Displayed Number



1. Locate the record in call history that you want to dial.
2. If you wish to change how the number is dialed, press #.
   The screen displays any alternate dialing sequences available for this call (area code + number; 1 + area code + number; number only; 1+ number).
3. When the number is correctly displayed for dialing, press SET, then press ◄ or ► until DIAL flashes.



4. Press SET.

   —OR—

   When the number is correctly displayed for dialing, press PHONE.



Store a Call History Record in the Directory

1. Locate the record in call history you want to store in memory.
2. If you wish to change how the number is stored,press #.
   The screen displays any alternate dialing sequences available for this call (area code + number; 1 + area code + number; number only;1+ number).
3. Press SET, then press ◀ or ▶ until PGM flashes.

```
DIAL PGM ERASE
      973-555-0123
      5/01 5:40PM OLD:28
```

4. Press SET three times to store the call record in memory without editing.

```
DISTINCT RING? N
9735550123
      5/01 5:40PM OLD:28
```

5. Press ◀ or ▶ to select Y or N for distinctive ring option.
6. Press SET. You'll hear a beep confirming that the name and number were stored.

DISPLAY SCREEN MESSAGES

SCREEN DISPLAYS:	*WHEN:*
PRIVATE	The other party is blocking name and/or number information.
OUT OF AREA	Your phone company is unable to receive information about this caller's name and/or number.
RINGING	There is a call coming in.
CONNECTING...	The handset is waiting for a dial tone.
PHONE ON	The handset is in use.
PAGING	The base is paging the handset.
HOLD	There is a call on hold.
NEEDS RECHARGING	The battery needs to be recharged.
BATTERY LOW	The battery needs to be recharged.
RINGER OFF	The handset ringer is off.
MESSAGE WAITING	You have received telephone company voice mail.

BATTERIES

Charge the Handset Battery Pack

- This battery should remain charged up to six days with the ringer turned on and up to 10 days with the ringer off. A fully charged battery provides an average talk time of about 10 hours.
- The battery pack needs charging when:
  — A new battery is installed in the handset.
  — The phone beeps twice every five seconds.
  — The screen displays BATTERY LOW and the low battery icon.
- Place the handset in the base so the CHARGING light turns on. The battery pack is typically fully charged in 10 hours.
- You can keep the battery fully charged by returning the handset to the base after each use.
- If you repeatedly get a low battery indicator, even after charging overnight,the battery should be replaced. Use only Replacement Battery 3301,SKU#91076.

CAUTION: To reduce the risk of fire or injury to persons or damage to the telephone, read and follow these instructions carefully:

Charge the battery provided with or identified for use with this product only in accordance with the instructions and limitations specified in the User's Manual, Part 1.

Replacing the Handset Battery Pack

1 **Remove the battery compartment cover** on the handset by pressing on the indentation and sliding the cover downward.

2 **Lift out the old battery pack and disconnect.**

3 **Align the two holes in the new battery pack's plug** with the socket pins,and snap the plug into place. Place the battery pack in the compartment with the wires in the lower left corner, along the bottom of the battery pack.

4 **Replace the cover** by sliding it up into place.

5 **The new battery pack must be charged before using the phone.** Place the handset in the base and allow it to charge for at least 12 hours the first charge. The telephone might operate before that,but for best performance,let the battery pack charge fully.



IN CASE OF DIFFICULTY

If you have difficulty operating this phone,try the suggestions below. For Customer Service,visit our website at ***www.telephones.att.com*** or call 1–800–222–3111. **Please retain your receipt as your proof of purchase**.

TELEPHONE OPERATION

PROBLEM	*SOLUTION*
If the phone doesn't work at all, check these items first:	• Make sure the AC adapter is plugged into an outlet not controlled by a wall switch. • Make sure the telephone line cord is plugged firmly into the base unit and the modular jack. • Make sure the base antenna is fully upright. • If the handset does not beep when you press PHONE, the battery might need charging. • Make sure the battery pack is installed correctly. • If you have dial pulse (rotary) service on your phone line,make sure the dial mode is set to dial pulse (see INSTALLATION). • Microwave appliances may cause interference with this phone.If you experience interference,move away from the microwave.
PROBLEM	*SOLUTION*
If the above suggestions don't solve the problem, try re-initializing the handset and base:	**1** Disconnect the power to the base. **2** Remove the handset battery pack. **3** Wait a few minutes. **4** Connect the power to the base. **5** Insert the handset battery pack. **6** Put the handset in the base to re-initialize.

TELEPHONE OPERATION

PROBLEM	*SOLUTION*
If you hear a two-beep signal when you try to use the handset:	• You might be out of range. Move close to the base and try again. • If moving closer to the base doesn't help, try following the directions above for re-initializing the handset and base.

PROBLEM	*SOLUTION*
If the phone does not ring when you receive a call:	• Make sure the handset ringer is on. • Make sure the telephone line cord is connected firmly to the base and the telephone jack. • Make sure the AC adapter is plugged firmly into an outlet not controlled by a wall switch. • You might be too far from the base;move closer. • You might have too many extension phones on your telephone line to allow all of them to ring. Try unplugging some of them.

PROBLEM	*SOLUTION*
If the *MESSAGE* light on the base does not go off even after you've listened to voice mail messages:	• Press PROG/CHAN. • Press ▶ unitil the screen displays MESSAGES WAITING. • Press SET. The screen displays LIGHTS OFF: YES. • Press SET again to turn off the MESSAGE light on base.

TELEPHONE OPERATION

PROBLEM	*SOLUTION*
If you hear noise or interference when using the phone:	• Make sure the base antenna is fully upright. • You may be out of range. Move closer to the base. • Press and release PROG/CHAN to change to another of the 30 channels available. If noise is exceptionally loud,move closer to the base before changing channels. • Household appliances plugged into the same circuit as the base can sometimes cause interference. Try moving the appliance or the base to another outlet. • Using the handset near household appliances (microwaves,computers, television,stereos,etc.) can sometimes cause interference. Move away from appliances while using the handset. • The layout of your home or office might be limiting the operating range. Try moving the base to another location, preferably on an upper floor. • If the buttons don't work,try placing the handset in the base for at least 15 seconds.

PROBLEM	*SOLUTION*
If you hear other calls while using your phone:	• Press PROG/CHAN to change to another channel. • Disconnect the base from the modular jack and plug in a corded telephone. If you still hear other calls,the problem is probably in your wiring or local service. Call your local telephone service company.

TELEPHONE OPERATION

PROBLEM	*SOLUTION*
If you lose a call after changing channels:	You were probably almost out of range. Move closer to the base before changing channels. Before placing another call,set the handset in the base for at least 15 seconds.
PROBLEM	***SOLUTION***
If you are unable to operate special telephone services or other equipment requiring touch tone signals:	If you have dial pulse (rotary) service, follow the directions under "Temporary Tone Dialing"in the TELEPHONE OPERATION section of this manual.
PROBLEM	***SOLUTION***
If the NEW CALL light on the base does not go off after you review your Caller ID information in the call log:	You may still have unreviewed (new) calls somewhere in your call history. Make sure you review your entire call history.

DEFAULT SETTINGS

DEFAULT SETTINGS

FUNCTION:	*DEFAULT SETTING:*
Dial Method	Tone
Handset Volume	1
Ringer Melody	RINGER: 1
Clock	1/01 12:00AM

TECHNICAL SPECIFICATIONS

TECHNICAL SPECIFICATIONS

RF Frequency Band (Handset to base)	912.75 MHz – 917.10 MHz
RF Frequency Band (Base to handset)	2411.15 MHz – 2418.40 MHz
Channels	30
Modulation	FM
Operating Temperature	0°C – 50°C
Base Unit Voltage	104 – 129 Vrms
Base Unit Voltage (AC Adapter Output)	9 Vdc @ 300mA
Handset Voltage	3.1 – 4.2 Vdc,600mAh

INDEX

A

answer a call 7

B

Base Unit 1

C

Call history 22,23,24,25,26
Call Waiting 7
Caller ID 2,22
Charge the handset battery 5

D

Date 5
Delete a Number/Name 15,20
Delete Records 24
Dial a Number 16,21,25
dialing mode 5
display screen message 27

E

Edit a Number/Name 14,19

F

Flash 7

H

Handset 1, 7, 10
handset battery 3,28,29
handset ringer 9
Handset Volume 7
Hold 7

L

lose a call after
changing channels 33

M

messages waiting 31

N

NiCd battery pack 1
not ring when you receive
a call 31

P

PROG/CHAN 5,7,9,11,12,17,18
PAGING 27
Page/Handset Locator 8
Power adapter 1
Power cord 4

R

redial 7
ringer style 9

S

Store a number/name 11,17

T

Telephone line cord 1
time 5

W

wall installation 6